

Basic Spinner adjustments

Spread Pattern is heavy in the middle

Adjust three of the six paddles on each spinner disc two notches in the hold direction. Alternating every other paddle. If still heavy in the middle move two more notches on the same paddles. If still heavy in the middle move the other set of paddles two notches in the hold direction.

Spread pattern is heavy on the outside

Adjust three of the six paddles two notches in the release direction. Alternating every other paddle. If still heavy on the outside move two more notches on the same paddles in the release direction. If still heavy on the outside move the other set of paddles two notches in the release direction.

